



Panther with North America PDU






Panther with International PDU



Power cords
 USB cables

Panther with North America UPS



- PRINTER
- LIS
- FIREWALL

C7 to NEMA 5-15
 C13 to NEMA 5-15
 C5 to NEMA 5-15

NEMA L5-20 to C19


POWER SUPPLY

NEMA 5-15 to C13

USB HUB

- To printer
- To monitor
- To Hanheld Scanner

Panther with International UPS



Power cords

USB cables